

launch




install peel 3d

a



browse licence
& calibration

a



launch peel 3d

connect



PSU to wall

b



PSU to cable

c



cable to laptop



cable to scanner

d





peel-3d.com/support | support@peel-3d.com

